


说明书



使用说明

1. 接通输出功率是 5V 2A 的电源（可以是移动电源或者是 5V2A 的手机插头），电源指示灯亮黄色；

1. Connected the 3D pen's power whose output power is 5V 2A (may be the mobile power supply or 5V2A mobile phone plug) , the power indicator lights yellow and can be used normally.



2. 单击进丝键，加热指示灯亮红色，开始预加热；

2. Click the filament enter button, the heating indicator lights red, and begin to heat up.



3. 加热指示灯变为绿色，预加热完成，单击进丝键，并将耗材加入进/退料口； 3. The heating indicator turns green. Pre heating is completed. Click on the filament enter button and add filament to the inport / outport.



4. 耗材挤出出料口，开始作画；
4. Filament extrudes the outlet, begin painting.



5. 3D 打印笔进丝/退丝过程中，单击任意按键暂停，再次单击进丝/退丝继续；
5. When 3D Print pen enters / returns the filament, click any button to pause, click again, the pen continues to work.
6. 单击退丝键，耗材自动退出进/退料口；
6. Click the filament return button, the filament automatically withdraws from the inport / outport.



7. 在使用 3D 打印笔过程中，无论是续丝还是换丝，我们都要保证耗材端部的平整性；
7. We have to ensure the loading port smooth filaments, whether loading or unloading the material in the process of using the 3D pen.



正确



错误



错误

警告！

Warning!

1. 此设备适用于 8 岁以上儿童和成人使用。儿童需要在成人监护下方可使用。
This equipment is suitable for children over 8 years of age and adult use. Children need to be used in the adult guardianship.
2. 此设备前段笔尖及附近为高温危险区域，严禁用手触摸或用笔尖触碰其他物品。
The equipment for high temperature near the anterior tip and dangerous region, therefore no pen touch other objects by hand touch.
3. 严禁用异物塞入进料孔。
It is strictly prohibited to use foreign body into the feed hole.
4. 该设备为精密电子仪器，请勿水淋。
The equipment for precision electronic instruments, do not water.
5. 使用后请放置于安全位置，以防高空跌落或儿童触摸。
Please put it in a safe place, to prevent falling from high altitude or the children touch.